View PDF	Print	Fmail	



Packable Wind Jacket. EB500

PRODUCT MEASUREMENTS

	XS	s	М	L	XL	2XL	3XL	4XL
Chest Width	21 1/2	23	24 1/2	26	27 1/2	29	31	33
Sleeve Length	34 3/4	35 1/2	36 1/4	37	37 3/4	38 1/2	39 1/4	40
Body Length at Back	28	28 1/2	29	29 1/2	30 1/2	31 1/2	32	32 1/2

CHEST WIDTH

SLEEVE LENGTH

Measured across the chest one inch below armhole when laid flat.

Start at center of neck and measure down shoulder, down sleeve to hem.

BODY LENGTH AT BACK

Measured from high point shoulder to finished hem at back.